

Značka	Model	CC	Rok	Přední	Zadní
BETA	250 RR 4T	250	05-	DF635	DF670
BETA	350 RR 4T	350	11-12	DF635	DF670
BETA	400 RR 4T	400	05-12	DF635	DF670
BETA	450 RR 4T	450	05-12	DF635	DF670
BETA	498 RR 4T	498	12-12	DF635	DF670
BETA	525 RR 4T	525	05-	DF635	DF670
HUSQVARNA	125 CR	125	00-03	DF635	DF885
HUSQVARNA	125 CR	125	04-04	DF635	DF885
HUSQVARNA	125 CR	125	05-	DF635	DF670
HUSQVARNA	125 SM S	125	00-	DF635	DF885
HUSQVARNA	125 SM S 4T	125	11-	DF635	DF885
HUSQVARNA	125 TE 4T	125	11-13	DF635	DF885
HUSQVARNA	125 WR	125	00-05	DF635	DF885
HUSQVARNA	125 WR	125	06-	DF635	DF670
HUSQVARNA	125 WRE	125	00-	DF635	DF885
HUSQVARNA	125 WXE	125	07-	DF635	
HUSQVARNA	250 CR	250	00-03	DF635	DF885
HUSQVARNA	250 CR	250	04-04	DF635	DF885
HUSQVARNA	250 CR	250	05-	DF635	DF670
HUSQVARNA	250 TC	250	04-04	DF635	DF885
HUSQVARNA	250 TC	250	05-13	DF635	DF670
HUSQVARNA	250 TE	250	05-	DF635	DF885
HUSQVARNA	250 TE R	250	13-13	DF635	DF885
HUSQVARNA	250 WR	250	00-	DF635	DF885
HUSQVARNA	300 WR	300	09-	DF635	DF885
HUSQVARNA	310 TE	310	09-	DF635	DF670
HUSQVARNA	310 TE R	310	13-	DF635	DF670
HUSQVARNA	360 WR	360	00-	DF635	DF885
HUSQVARNA	449 TE	449	11-	DF635	DF670
HUSQVARNA	450 TC	450	05-	DF635	DF670
HUSQVARNA	450 TE	450	05-	DF635	DF670
HUSQVARNA	510 TC	510	04-04	DF635	DF885
HUSQVARNA	510 TC	510	05-	DF635	DF670
HUSQVARNA	510 TE	510	00-04	DF635	DF885
HUSQVARNA	510 TE	510	05-	DF635	DF670
HUSQVARNA	570 TE	570	00-	DF635	DF885
HUSQVARNA	610 TC	610	00-	DF635	DF885
HUSQVARNA	610 TE	610	00-	DF635	DF885
HUSQVARNA	630 TE	630	10-	DF635	DF885
HUSQVARNA	TC 449	450	11-	DF635	DF885
HUSQVARNA	TE 410/E	410	00-	DF635	DF885
HUSQVARNA	TE 449	450	11-	DF635	DF885
HUSQVARNA	TE 511	511	11-	DF635	DF885

OSSA	ENDURO 300i	300	12-	DF635	
SWM	MC 250 S	250	16-	DF635	DF670
SWM	RS 125 R	125	16-	DF635	DF670
SWM	RS 300 R	300	16-	DF635	DF670
SWM	RS 340 S	340	16-	DF635	DF670
SWM	RS 500 R	500	16-	DF635	DF670
SWM	RS 650 R	650	16-	DF635	DF885
SWM	SM 125 R	125	16-	DF635	DF670